



**FR**

- 1** Procéder à la découpe en croix de l'étanchéité
- 2** Si présence isolant découper ce dernier
- 3** Placer Ventélia dans l'empreinte de la découpe
- 4** Rabattre l'étanchéité sur la plaque et les coller entre eux (ou bien les souder selon les procédés)
- 5** Compléter l'étanchéité par une bande roulée sur la remontée de l'embase
- 6** Emboîter la sortie de toit sur son support
- 7** Procéder à la mise à niveau et serrer les vis six pans avec la clé à lèvre prévue à cet effet.

**EN**

- 1** Cut the roof membrane in a cross shape to allow it to be folded back for use later on (do not completely cut membrane away, see step 4)
- 2** If necessary, remove the roof insulation as well.
- 3** Place the flashing in position
- 4** Overlap the roof membrane over the flashing edges
- 5** Add a piece of roof membrane around the flashing upstand to ensure water tightness
- 6** Seat Ventelia stack on its flashing base.
- 7** Check if Ventelia stack is level and adjust if necessary. Use an allen key to secure Ventelia to its flashing.